


# POP VENT AIR INTAKE PLACEMENT INSTRUCTION FOR A METAL ROOF


The following is our recommendation for the proper placement of the Pop Vent if installed between the metal ribs.

The Vent should be placed approx. 12" to 24" from bottom of roof.


On homes that require 2 Pop Vents, they should be placed approx. 1/4 of the total length in from each end. As an example, on an 80' home the vents would be placed approx. 20' in from each end.



On homes that require 3 Pop Vents, one vent should be in the center and the other 2 approx. 1/6 in from each end. As an example, on an 80' home 2 vents would be placed approx. 13' in from each end, and one would be in the center.




On homes that require 4 Pop Vents, 2 vents should be placed approx. 1/8 in from each end and 2 vents should be placed approx. 3/8 in from each end. As an example, on an 80' home 2 vents would be placed approx. 10' in from each end and 2 vents would be placed 30' in from each end.



## INSTALLATION INSTRUCTIONS

1. For the PV-8 cut a round 8" opening (for the PV-14, cut a round 14" opening) in the metal panel between the ribs, and through the roof deck below.
2. Apply butyl tape or caulking to underside of flange.
3. Place vent over circular opening (on metal roof) and fasten using #10 min. 1/2" long sheet metal screws, max 4" on center.
4. Apply caulk to cover fastener.



**ACTIVE VENTILATION PRODUCTS, INC.**

**800-247-3463 845-565-7770**

www.roofvents.com • E-mail: roofvents@aol.com • Fax 845-562-8963